


**TTP-2410MU/ TTP-346MU/ TTP-644MU/  
TTP-2410MT/ TTP-346MT/ TTP-644MT Series**

**THERMAL TRANSFER / DIRECT THERMAL  
BAR CODE PRINTER**

**SERVICE  
MANUAL**



# TABLE OF CONTENT

<b>1. FUNDAMENTAL OF THE SYSTEM .....</b>	<b>2</b>
1.1. Overview.....	2
<b>2. ELECTRONICS.....</b>	<b>7</b>
2.1 Summary of Board Connectors.....	7
2.2 Interface Pin Configuration.....	11
<b>3. MECHANISM .....</b>	<b>13</b>
3.1 Remove Covers and the Lower Front Panel.....	13
3.2 Replacing the LCD Panel Module for MU series .....	15
3.3 Replacing the Touch Panel Module for MT series.....	16
3.3 Replacing the Power Supply Unit.....	18
3.4 Replacing Multi-interface Board.....	19
3.5 Replacing the Main Board.....	20
3.6 Replacing the Platen Roller Assembly.....	21
3.7 Replacing the Stepping Motor .....	22
3.8 Replacing the Print head ASS'Y .....	23
3.9 Replacing the Gap/Black Mark Sensor Module.....	25
3.10 Replacing the Ribbon Rewind Spindle .....	27
3.11 Cutter Module Installation (Option) .....	28
3.12 Peel-off Kit Installation (Option) .....	29
3.13 Internal Rewinding Kit Installation (Option) .....	34
3.14 Replacing the Cutter Driver IC Board (Option).....	37
3.15 Slot-in Wireless Housing Installation (Option).....	38
<b>4. TROUBLESHOOTING .....</b>	<b>41</b>
4.1 Common Problems.....	41
4.2 Mechanism Fine Adjustment to Avoid Ribbon Wrinkles .....	45
4.3 Adjustment Knob .....	47
4.3.1 Print head Pressure Adjustment Knob .....	47
4.3.2 Ribbon Tension Adjustment Knob .....	48
4.3.3 Print Head Burn Line Adjustment Knob.....	49
<b>5. MAINTENANCE.....</b>	<b>50</b>
<b>UPDATE HISTORY .....</b>	<b>52</b>

# 1. FUNDAMENTAL OF THE SYSTEM

## 1.1. Overview

### Front View

**For MU series**




- 1.** LED indicators
- 2.** LCD display
- 3.** Operation buttons
- 4.** Media view window
- 5.** Paper exit chute
- 6.** Printer cover

## For MT series




- 1.** LED indicators
- 2.** Touch screen
- 3.** Operation buttons
- 4.** Media view window
- 5.** Paper exit chute
- 6.** Printer cover

## Interior View



## Rear View



### \* Recommended SD card specification


Type	SD card spec	SD card capacity	Approved SD card manufacturer
SDHC	V2.0 Class 4	2G	Transcend
	V3.0 Class 10	32G	Kingston

	V3.0 Class 10	16G	Kingston
	V2.0 Class 4	8G	Scandisk
	V3.0 Class 10	32G	Scandisk
Micro SD	V2.0 Class 4	4G	Transcend
	V2.0 Class 4	8G	Transcend
	V3.0 Class 10 UHS-I	16G	Transcend
	V3.0 Class 10 UHS-I	32G	Transcend
	V3.0 Class 10	16G	Kingston
	V2.0 Class 4	16G	Scandisk
	V3.0 Class 10 UHS-I	16G	Scandisk
<ul style="list-style-type: none"> <li>- The DOS FAT file system is supported for the SD card.</li> <li>- Folders/files stored in the SD card should be in the 8.3 filename format.</li> <li>- The miniSD/microSD card to SD card slot adapter is required.</li> </ul>			







## 2. ELECTRONICS




### 2.1 Summary of Board Connectors

#### Main board




Connector	Description
1	Ethernet RJ-45 connector
2	SD card slot
3	USB device connector
4	USB host connector
5	RS-232C connector
6	Microprocessor
7	GPIO connector
8	Centronics port FPC connector

9	TFT LCD panel FPC connector																																	
10	KEY & LED connector																																	
11	LCD panel connector																																	
12	USB host internal connector (Reserve)																																	
13	I2C internal connector (Reserve)																																	
14	RFID module connector (4" 6pin / 6" or 8" 4pin)																																	
15	Ribbon recover sensor connector (For 4" used only)																																	
	<table border="1"> <tr> <td rowspan="4">  </td> <th>Pin</th> <th>Description</th> <th>Voltage</th> </tr> <tr> <td>1</td> <td>GND</td> <td>0V</td> </tr> <tr> <td>2</td> <td>Ribbon encoder sensor receiver</td> <td>A/D: 0~3.3V</td> </tr> <tr> <td>3</td> <td>Ribbon encoder sensor emitter power pin</td> <td>4.0~4.15V</td> </tr> </table>		Pin	Description	Voltage	1	GND	0V	2	Ribbon encoder sensor receiver	A/D: 0~3.3V	3	Ribbon encoder sensor emitter power pin	4.0~4.15V																				
	Pin		Description	Voltage																														
	1		GND	0V																														
	2		Ribbon encoder sensor receiver	A/D: 0~3.3V																														
	3	Ribbon encoder sensor emitter power pin	4.0~4.15V																															
16	Power supply output (24V DC) connector																																	
17	Stepping motor connector																																	
18	Print head data connector																																	
19	Print head power connector																																	
20	Cutter/peel-off sensor connector																																	
	<table border="1"> <tr> <td rowspan="10">  </td> <th>Pin</th> <th>Description</th> <th>Voltage</th> </tr> <tr> <td>1</td> <td>Cutter enable</td> <td>0V: Cutter work 5V: Cutter stop</td> </tr> <tr> <td>2</td> <td>Cutter direction</td> <td>0V: Cutter positive cut 5V: Cutter negative cut</td> </tr> <tr> <td>3</td> <td>Cutter position sensor switch</td> <td>0V: Cutter stop 3.3V: Cutter work</td> </tr> <tr> <td>4</td> <td>Peel sensor receiver</td> <td>A/D: 0~3.3V</td> </tr> <tr> <td>5</td> <td>N/A</td> <td>N/A</td> </tr> <tr> <td>6</td> <td>Logic power</td> <td>5V</td> </tr> <tr> <td>7</td> <td>GND</td> <td>0V</td> </tr> <tr> <td>8</td> <td>Cutter power</td> <td>24V</td> </tr> <tr> <td>9</td> <td>I2C SCL signal</td> <td></td> </tr> <tr> <td>10</td> <td>I2C SDA signal</td> <td></td> </tr> </table> <p><b>Note:</b> 9 Pin Mini Din for cutter/peel-off module connector</p>		Pin	Description	Voltage	1	Cutter enable	0V: Cutter work 5V: Cutter stop	2	Cutter direction	0V: Cutter positive cut 5V: Cutter negative cut	3	Cutter position sensor switch	0V: Cutter stop 3.3V: Cutter work	4	Peel sensor receiver	A/D: 0~3.3V	5	N/A	N/A	6	Logic power	5V	7	GND	0V	8	Cutter power	24V	9	I2C SCL signal		10	I2C SDA signal
	Pin		Description	Voltage																														
	1		Cutter enable	0V: Cutter work 5V: Cutter stop																														
	2		Cutter direction	0V: Cutter positive cut 5V: Cutter negative cut																														
	3		Cutter position sensor switch	0V: Cutter stop 3.3V: Cutter work																														
	4		Peel sensor receiver	A/D: 0~3.3V																														
	5		N/A	N/A																														
	6		Logic power	5V																														
	7		GND	0V																														
	8		Cutter power	24V																														
	9	I2C SCL signal																																
10	I2C SDA signal																																	
21	Head open sensor connector																																	

		<table border="1"> <thead> <tr> <th>Pin</th> <th>Description</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Head open sensor emitter power pin</td> <td>1.2~1.4V</td> </tr> <tr> <td>2</td> <td>GND</td> <td>0V</td> </tr> <tr> <td>3</td> <td>Logic power</td> <td>3.3V</td> </tr> <tr> <td>4</td> <td>Head open sensor receiver</td> <td>0V: Head close 3.3V: Head open</td> </tr> </tbody> </table>	Pin	Description	Voltage	1	Head open sensor emitter power pin	1.2~1.4V	2	GND	0V	3	Logic power	3.3V	4	Head open sensor receiver	0V: Head close 3.3V: Head open			
Pin	Description	Voltage																		
1	Head open sensor emitter power pin	1.2~1.4V																		
2	GND	0V																		
3	Logic power	3.3V																		
4	Head open sensor receiver	0V: Head close 3.3V: Head open																		
22	Ribbon sensor connector																			
		<table border="1"> <thead> <tr> <th>Pin</th> <th>Description</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Ribbon sensor receiver</td> <td>A/D: 0~3.3V</td> </tr> <tr> <td>2</td> <td>Ribbon sensor emitter power pin</td> <td>5V</td> </tr> <tr> <td>3</td> <td>GND</td> <td>0V</td> </tr> <tr> <td>4</td> <td>Ribbon sensor emitter</td> <td>4.0~4.1V: Emitter on 4.3~4.4V: Emitter off</td> </tr> </tbody> </table>	Pin	Description	Voltage	1	Ribbon sensor receiver	A/D: 0~3.3V	2	Ribbon sensor emitter power pin	5V	3	GND	0V	4	Ribbon sensor emitter	4.0~4.1V: Emitter on 4.3~4.4V: Emitter off			
Pin	Description	Voltage																		
1	Ribbon sensor receiver	A/D: 0~3.3V																		
2	Ribbon sensor emitter power pin	5V																		
3	GND	0V																		
4	Ribbon sensor emitter	4.0~4.1V: Emitter on 4.3~4.4V: Emitter off																		
23	Gap sensor connector																			
		<table border="1"> <thead> <tr> <th>Pin</th> <th>Description</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Power</td> <td>5V</td> </tr> <tr> <td>2</td> <td>Gap sensor emitter</td> <td>4.0~4.1V: Emitter on 4.3~4.4V: Emitter off</td> </tr> <tr> <td>3</td> <td>Black mark sensor emitter</td> <td>4.0~4.1V: Emitter on 4.3~4.4V: Emitter off</td> </tr> <tr> <td>4</td> <td>Gap and black mark sensor receiver</td> <td>A/D: 0~3.3V</td> </tr> <tr> <td>5</td> <td>GND</td> <td>0V</td> </tr> </tbody> </table>	Pin	Description	Voltage	1	Power	5V	2	Gap sensor emitter	4.0~4.1V: Emitter on 4.3~4.4V: Emitter off	3	Black mark sensor emitter	4.0~4.1V: Emitter on 4.3~4.4V: Emitter off	4	Gap and black mark sensor receiver	A/D: 0~3.3V	5	GND	0V
Pin	Description	Voltage																		
1	Power	5V																		
2	Gap sensor emitter	4.0~4.1V: Emitter on 4.3~4.4V: Emitter off																		
3	Black mark sensor emitter	4.0~4.1V: Emitter on 4.3~4.4V: Emitter off																		
4	Gap and black mark sensor receiver	A/D: 0~3.3V																		
5	GND	0V																		

## GPIO with multi-interface board




Connector	Description	Remark
1	GPIO connector	
2	GPIO power and control signal connector	
3	Centronics port connector	
4	Centronics port FPC connector	

## 2.2 Interface Pin Configuration

### RS-232C

PIN	CONFIGURATION
1	+5 V
2	TXD
3	RXD
4	CTS
5	GND
6	RTS
7	N/C
8	RTS
9	N/C

### USB

	PIN	CONFIGURATION
	1	N/C
	2	D-
	3	D+
	4	GND

### Centronics


Pin	SPP Mode	Nibble	In/Out	Function
1	Strobe	N/A	In	A <b>low</b> on this line indicates that there are valid data at the host. When this pin is de-asserted, the +ve clock edge should be used to shift the data into the device.
2-9	Data 0-7	N/A	In	Data Bus. Single-directional.
10	Ack	N/A	Out	A <b>low</b> on this line indicates that there are valid data at the Device. When this pin is de-asserted, the +ve clock edge should be used to shift the data into the host.
11	Busy	N/A	Out	When in reverse direction, a <b>high</b> indicates data, while a <b>low</b> indicates a command cycle. In forward direction, it functions as PtrBusy.
12	Paper Out /	N/A	Out	When <b>low</b> , device acknowledges reverse request.

	End			
13	Select	N/A	Out	Extensibility flag
14	Ground	N/A	GND	
15	No Defined	N/A	N/A	
16-17	Ground	N/A	GND	Ground
18	No Defined	N/A	N/A	
19-30	Ground	N/A	GND	Ground
31	No Defined	N/A	N/A	
32	Error / Fault	N/A	Out	A <b>low</b> set by the device indicates that the reverse data is available
33-35	Ground	N/A	GND	Ground
36	No Defined	N/A	N/A	

## Ethernet

PIN	CONFIGURATION
1	<b>Tx+</b>
2	<b>Tx-</b>
3	<b>Rx+</b>
4	<b>N/C</b>
5	<b>N/C</b>
6	<b>Rx-</b>
7	<b>N/C</b>
8	<b>N/C</b>

## GPIO




### 3. MECHANISM

#### 3.1 Remove Covers and the Lower Front Panel


1. Remove two screws on rear of printer.




2. Open printer right side cover and remove two screws then close the cover.



3. Push the printer left side electronics cover toward the interface direction then take it out from the printer. Please refer to the following pictures.




4. Remove 3 screws from each hinge. Be careful the right side cover may fall out from the printer. Take out the right side cover from the printer.



5. Reassemble the parts in the reverse procedures.

## 3.2 Replacing the LCD Panel Module for MU series


1. Refer to section 3.1 to remove the electronics cover.
2. Disconnect harness from the LCD panel module.
3. Push two tabs to remove/replace the LCD panel module.




4. Remove five screws to remove/replace LCD panel PCB ASS'Y and LCD panel ASS'Y.
5. Reassemble the parts in the reverse procedures.

### 3.3 Replacing the Touch Panel Module for MT series


1. Refer to section 3.1 to remove the electronics cover.
2. Remove 1 screw to release ground cable. Loosen the connector lock to disconnect the flat cable from panel module carefully.



3. Push two tabs for touch panel module. Disconnect 2 connectors to remove/replace the touch panel module.




4. Reassemble the parts in the reverse procedures. If the flat cable on panel module is difficult to connect back, please remove it on main board and loose 2 cable ties to install.



### 3.3 Replacing the Power Supply Unit

1. Refer to section 3.1 to remove the electronics cover.
2. Disconnect all connectors on the power supply unit.
3. Remove 2 screws and 2 cable ties.




--- Connector

--- Screw

4. Remove/Replace the power supply unit.
5. Reassemble the parts in the reverse procedures.

### 3.4 Replacing Multi-interface Board

1. Refer to section 3.1 to remove the electronics cover.
2. Remove 2 screws. Disconnect 1 flat cable. Remove/Replace the multi-interface board.




3. Reassemble the parts in the reverse procedures.

### 3.5 Replacing the Main Board

1. Refer to section 3.4 to remove the multi-interface board.
2. Remove 4 screws then take off the interface bracket.




2. Remove 2 screws and 2 copper pillars on the main board. Disconnect all connectors from the main board. Remove/Replace the main board.




3. Reassemble the parts in the reverse procedures.

### 3.6 Replacing the Platen Roller Assembly


1. Open printer right side cover.
2. Disengage print head lift lever.
3. Remove 2 screws to remove lower front panel.



4. Remove 2 screws on the platen holder.




5. Take out the platen holder, platen roller assembly and replace a new platen roller assembly.



6. Reassemble the parts in the reverse procedures.

### 3.7 Replacing the Stepping Motor


1. Refer to section 3.1 to remove the electronics cover.
2. Disconnect the stepping motor connector. Remove 2 screws on the stepping motor.




3. Remove/Replace the stepping motor.
4. Reassemble the parts in the reverse procedures.

### 3.8 Replacing the Print head ASS'Y


1. Open the printer right side cover.
2. Turn the two print head pressure adjustment knobs counterclockwise to lowest index to minimize the pressure applied to the print head.
3. Disengage print head release lever.
4. Remove the screw upon the print head mechanism.





5. Carefully disconnect connector from the print head ASS'Y. Please do not pull the cable to right and left side alternatively in order to disconnect it from the print head connector. Please use the flat screw driver to push at the key in the middle of the connector. When the connector becomes loose from the print head connector, you can disconnect it.



6. Remove/Replace the print head ASS'Y.
7. Connect the print head cable and carefully slide assembly into the print mechanism. Make sure the two locating protrusions on the print mechanism mounting plate snap into the locating holes on the print head.
  - Locating protrusions
  - Locating holes



8. Check the print head has been totally closed to the print mechanism before secure the print head by the previously removed thumbscrew.




9. Reassemble the parts in the reverse procedures.


**Note: Please use the come with new print head screw to replace the print head assembly. DO NOT use the original screw.**

### 3.9 Replacing the Gap/Black Mark Sensor Module


1. Refer to section 3.1 to remove the electronics cover.
2. Disconnect the gap/black mark sensor connector on the main board.



3. Open the printer right side cover.
4. Unlock the media sensor lock lever.
5. Make the media sensor module approach the end of mechanism but not too close.
6. At the bottom of the gap/black mark sensor module, there is a green plastic tab to latch the sensor module to the mechanism. Use a piece of label/paper which can fit the path of the media sensor module and make the label/paper through the path and under the tab.




4. Pull the media sensor module and the label/paper and pull the media sensor module out of the latch of the sensor module to the mechanism.




6. Replacing the gap/black mark sensor is pushing the gap/black mark sensor that is reassembling the parts in the reverse procedures but using the piece of label/paper is not necessary.

### 3.10 Replacing the Ribbon Rewind Spindle


1. Refer to section 3.1 to remove the electronics cover.
2. Remove 1 E-ring.



3. Remove the ribbon rewind spindle gear.



4. Remove the E-ring that fixes the spindle at the mechanism.



5. Remove/Replace the ribbon rewind spindle.
6. Reassemble the parts in the reverse procedures.

### 3.11 Cutter Module Installation (Option)


1. Open the printer right side cover.
2. Remove 2 screws to remove lower front panel.



3. Plug the cutter mini DIN cable connector into the cutter/peel-off module connector. The triangle mark on the connector must be at the upper side.



4. Attach the cutter module to the front of the platen roller. Align the cutter bracket screw holes to the screw holes that fix the lower front panel.
5. Fasten the 2 screws at the cutter bracket to fix the cutter module to the printer mechanism.




### 3.12 Peel-off Kit Installation (Option)


#### Peel-off kit parts list




1. Refer to section 3.1 to remove the electronics cover.
2. Fasten the screw#2 to fix the gear#1.



3. Fasten the screw#2 to fix the gear#2.




4. Put the bearing into the internal rewind hole.



5. Open the printer right side cover.


6. Remove the dustproof cover from the internal rewind hole and put the bearing into it.



7. Insert the internal rewind into the hole.



8. Use the E-ring driver and hammer to fix the internal rewind by E-ring.



**\*How to assemble e-ring?**

a. Put E-ring into E-ring driver.




b. Put the E-ring on roller niche.



c. Use hammer to fix e-ring and roller.




9. Insert the gear (with spring) into the spindle and fix it with E-ring. Install back the electronics cover.




10. Remove 2 screws to remove lower front panel.





11. Plug the peel-off mini DIN cable connector into the cutter/peel-off connector. The triangle mark on the connector must be at the upper side.



12. Attach the peel-off module to the front of the platen roller. Align the peel-off module screw holes to the screw holes that fix the lower front panel. Fasten the 2 screws at the peel-off module to fix the peel-off module to the printer mechanism.




14. Close the peel-off module cover.




### 3.13 Internal Rewinding Kit Installation (Option)


#### Internal rewinding kit parts list




1. Refer to section 3.1 to remove the electronics cover.
2. Fasten the screw#2 to fix the gear#1.



3. Fasten the screw#2 to fix the gear#2.




4. Put the bearing into the internal rewind hole.




5. Open the printer right side cover.


6. Remove the dustproof cover from the internal rewind hole and put the bearing into it.




7. Insert the internal rewind into the hole.



8. Use the E-ring driver and hammer to fix the internal rewind by E-ring. (Please refer to the section 3.13 for “How to assemble e-ring?”)




9. Insert the gear (with spring) into the spindle and fix it with E-ring.



10. Refer to section 3.1 to remove the lower front panel.

11. Fasten the 2 screws to fix the label redirect front panel to the printer mechanism.



### 3.14 Replacing the Cutter Driver IC Board (Option)

1. Remove 4 screws on cutter cover.




2. Disconnect 1 connector on the cutter driver IC board. Remove 2 screws to replace the cutter driver IC board.




6. Reassemble the parts in the reverse procedures.

### 3.15 Slot-in Wireless Housing Installation (Option)


1. Refer to section 3.1 to remove the electronics cover.
2. Refer to section 3.4 & section 3.5 to remove the multi-interface board and to replace the main board.
3. Remove 4 screws to replace the plate for slot-in Wireless housing.




4. Install the housing into the plate, and fasten 2 screws to fix it.



5. Connect the housing board cable to the main board.



6. **Make sure the LCD flat cable (white) is fixed on front of printer by a label.** If not, please paste the label that included within kit on plate to fix the LCD flat cable on front of printer. (as picture shown)



7. Reassemble the parts in the reverse procedures.



## 4. TROUBLESHOOTING


### 4.1 Common Problems

The following guide lists the most common problems that might be encountered when operating this bar code printer. If the printer still does not function after all suggested solutions have been invoked, please contact the Customer Service Department of your purchased reseller or distributor for assistance.

Problem	Possible Cause	Recovery Procedure
<b>Power indicator does not illuminate</b>	<ul style="list-style-type: none"> <li>* The power cord is not properly connected.</li> </ul>	<ul style="list-style-type: none"> <li>* Plug the power cord in printer and outlet.</li> <li>* Switch the printer on.</li> </ul>
<b>Carriage Open</b>	<ul style="list-style-type: none"> <li>* The printer carriage is open.</li> </ul>	<ul style="list-style-type: none"> <li>* Please close the print carriage.</li> </ul>
<b>No Ribbon</b>	<ul style="list-style-type: none"> <li>* Running out of ribbon.</li> <li>* The ribbon is installed incorrectly.</li> <li>* The ribbon sensor is not been well calibrated.</li> </ul>	<ul style="list-style-type: none"> <li>* Supply a new ribbon roll.</li> <li>* Please refer to the steps in user's manual to reinstall the ribbon.</li> </ul>
<b>No Paper</b>	<ul style="list-style-type: none"> <li>* Running out of label.</li> <li>* The label is installed incorrectly.</li> <li>* Gap/black mark sensor is not calibrated.</li> </ul>	<ul style="list-style-type: none"> <li>* Supply a new label roll.</li> <li>* Please refer to the steps in user's manual to reinstall the label roll.</li> <li>* Calibrate the gap/black mark sensor.</li> </ul>
<b>Paper Jam</b>	<ul style="list-style-type: none"> <li>* Gap/black mark sensor is not set properly.</li> <li>* Make sure label size is set properly.</li> <li>* Labels may be stuck inside the printer mechanism.</li> </ul>	<ul style="list-style-type: none"> <li>* Calibrate the gap/black mark sensor.</li> <li>* Set label size correctly.</li> </ul>
<b>Take Label</b>	<ul style="list-style-type: none"> <li>* Peel function is enabled.</li> </ul>	<ul style="list-style-type: none"> <li>* If the peeler module is installed, please remove the label.</li> <li>* If there is no peeler module in front of the printer, please switch off the printer and install it.</li> <li>* Check if the connector is plugging correctly.</li> </ul>
<b>UP: Fwd.</b> <b>DOWN: Rev.</b> <b>MENU: Exit</b>	<ul style="list-style-type: none"> <li>* Cutter jam.</li> <li>* There is no cutter installed on the printer.</li> <li>* Cutter PCB is damaged.</li> </ul>	<ul style="list-style-type: none"> <li>* If the cutter module is installed, please press UP or DOWN key to rotate the cutter up or down to make the knife back to the right position.</li> <li>* Remove the label.</li> <li>* Make sure the thickness of label is less than 200 g/m2 (for regular cutter) or 300 g/m2 (for heavy duty cutter).</li> <li>* Replace a cutter PCB.</li> </ul>




<p><b>Not Printing</b></p>	<p>* Cable is not well connected to serial or USB interface or parallel port.          * The serial port cable pin configuration is not pin to pin connected.</p>	<p>* Re-connect cable to interface.          * If using serial cable,          - Please replace the cable with pin to pin connected.          - Check the baud rate setting. The default baud rate setting of printer is 9600,n,8,1.          * If using the Ethernet cable,          - Check if the Ethernet RJ-45 connector green LED is lit on..          - Check if the Ethernet RJ-45 connector amber LED is blinking.          - Check if the printer gets the IP address when using DHCP mode.          - Check if the IP address is correct when using the static IP address.          - Wait a few seconds let the printer get the communication with the server then check the IP address setting again.          * Change a new cable.          * Ribbon and media are not compatible.          * Verify the ribbon-inked side.          * Reload the ribbon again.          * Clean the printhead.          * The print density setting is incorrect.          * Printhead's harness connector is not well connected with printhead. Turn off the printer and plug the connector again.          * Check if the stepping motor is plugging in the right connector.          * Check your program if there is a command PRINT at the end of the file and there must have CRLF at the end of each command line.</p>
<p><b>Memory full ( FLASH / DRAM )</b></p>	<p>* The space of FLASH/DRAM is full.</p>	<p>* Delete unused files in the FLASH/DRAM.          * The max. numbers of file of DRAM is 50 files.          * The max. user addressable memory space of DRAM is 256 KB          * The max. numbers of file of FLASH is 256 files.          * The max. user addressable memory space of FLASH is 2560 KB for TTP-246M Pro and TTP-344M Pro and 6656KB for TTP-2410M Pro and TTP-346M Pro.</p>
<p><b>SD card is unable to use</b></p>	<p>* SD card is damaged.          * SD card doesn't insert correctly.          * Use the non-approved SD card manufacturer.</p>	<p>* Use the supported capacity SD card.          * Insert the SD card again.          * The supported SD card spec.          - 128MB          - 256MB          - 512MB          - 1GB          - 4GB SDHC CLASS 6          * Approved SD card manufacturers; SanDisk, Transcend</p>
<p><b>PS/2 port does not work</b></p>	<p>* Did not turn off power prior to plug in the PS/2 keyboard          * PS/2 keyboard is damaged.          * PS/2 keyboard doesn't plug-in correctly.          * There is no BAS file in the printer.</p>	<p>* Turn off printer power prior to plug in the PS/2 keyboard .          * Plug the PS/2 keyboard again.          * Make sure the keyboard is fine.          * Make sure if there is any BAS file downloaded into printer.</p>

<p><b>Poor Print Quality</b></p>	<ul style="list-style-type: none"> <li>* Ribbon and media is loaded incorrectly</li> <li>* Dust or adhesive accumulation on the print head.</li> <li>* Print density is not set properly.</li> <li>* Printhead element is damaged</li> <li>* Ribbon and media are incompatible.</li> <li>* The printhead pressure is not set properly</li> </ul>	<ul style="list-style-type: none"> <li>* Reload the supply.</li> <li>* Clean the printhead.</li> <li>* Clean the platen roller.</li> <li>* Adjust the print density and print speed.</li> <li>* Run printer self-test and check the print head test pattern if there is dot missing in the pattern.</li> <li>* Change proper ribbon or proper label media.</li> <li>* Adjust the printhead pressure adjustment knob. <ul style="list-style-type: none"> <li>- If the left side printout is too light, please adjust the left side pressure adjustment knob to the higher index (higher pressure). If the pressure adjustment knob has been adjust to index "5" and the poor print quality is still at the left side of the printout, please adjust the pressure adjustment knob to index "1" and use the Z-axis adjustment knob to fine tune the pressure.</li> <li>- If the right side printout is too light, please adjust the right side pressure adjustment knob to the higher index (higher pressure) to improve the print quality.</li> </ul> </li> <li>* If the label thickness is more than 0.22 mm, the print quality might be good enough, please adjust the heater line adjustment screw counter clockwise to get the best print quality.</li> <li>* The release lever does not latch the printhead properly.</li> </ul>
<p><b>LCD panel is dark and keys are not working.</b></p>	<ul style="list-style-type: none"> <li>* The cable between main PCB and LCD panel is loose.</li> </ul>	<ul style="list-style-type: none"> <li>* Check if the cable between main PCB and LCD is secured or not.</li> </ul>
<p><b>LCD panel is dark but the LEDs are light.</b></p>	<ul style="list-style-type: none"> <li>* The printer initialization is unsuccessful.</li> </ul>	<ul style="list-style-type: none"> <li>* Turn OFF and ON the printer again.</li> <li>* Initialize the printer.</li> </ul>
<p><b>LCD panel is dark and LEDs are lit on, but the label is feeding forward.</b></p>	<ul style="list-style-type: none"> <li>* The LCD panel harness connector is loose.</li> </ul>	<ul style="list-style-type: none"> <li>* The LCD panel harness connector is plugged upside down.</li> </ul>
<p><b>Ribbon encoder sensor doesn't work.</b></p>	<ul style="list-style-type: none"> <li>* The ribbon encoder sensor connector is loose.</li> </ul>	<ul style="list-style-type: none"> <li>* Fasten the connector.</li> </ul>
<p><b>Ribbon end sensor doesn't work.</b></p>	<ul style="list-style-type: none"> <li>* The connector is loose.</li> <li>* The ribbon sensor hole is covered with dust.</li> </ul>	<ul style="list-style-type: none"> <li>* Check the connector.</li> <li>* Clear the dust in the sensor hole by the blower.</li> </ul>
<p><b>Peel sensor is not working.</b></p>	<ul style="list-style-type: none"> <li>* Peel sensor is not located on the correct position.</li> <li>* The connector is loose.</li> </ul>	<ul style="list-style-type: none"> <li>* Make sure that the media goes through the Peel sensor.</li> <li>* Plug the connect cable correctly.</li> </ul>
<p><b>Cutter is not working.</b></p>	<ul style="list-style-type: none"> <li>* The connector is loose.</li> </ul>	<ul style="list-style-type: none"> <li>* Plug in the connect cable correctly.</li> </ul>
<p><b>Label feeding is not stable (skew) when printing.</b></p>	<ul style="list-style-type: none"> <li>* The media guide does not touch the edge of the media.</li> </ul>	<ul style="list-style-type: none"> <li>* If the label is moving to the right side, please move the label guide to left.</li> <li>* If the label is moving to the left side, please move the label guide to right.</li> </ul>
<p><b>Skip labels when printing.</b></p>	<ul style="list-style-type: none"> <li>* Label size is not specified properly.</li> <li>* Sensor sensitivity is not set properly.</li> <li>* The media sensor is covered with dust.</li> </ul>	<ul style="list-style-type: none"> <li>* Check if label size is setup correctly.</li> <li>* Calibrate the sensor by Auto Gap or Manual Gap options.</li> <li>* Clear the GAP/Black mark sensor by blower.</li> </ul>

<p><b>The printing position of small label is incorrect.</b></p>	<ul style="list-style-type: none"> <li>* Media sensor sensitivity is not set properly.</li> <li>* Label size is incorrect.</li> <li>* The parameter Shift Y in the LCD menu is incorrect.</li> <li>* The vertical offset setting in the driver is incorrect.</li> </ul>	<ul style="list-style-type: none"> <li>* Calibrate the sensor sensitivity again.</li> <li>* Set the correct label size and gap size.</li> <li>* Press [MENU] → [SELECT] x3 → [DOWN]x6 → [SELECT] to fine tune the parameter of Shift Y.</li> <li>* If using the software BarTender, please set the vertical offset in the driver.</li> </ul> 
<p><b>The left side printout position is incorrect.</b></p>	<ul style="list-style-type: none"> <li>* Wrong label size setup.</li> <li>* The parameter Shift X in LCD menu is incorrect.</li> </ul>	<ul style="list-style-type: none"> <li>* Set the correct label size.</li> <li>* Press [MENU] → [SELECT] x 3 → [DOWN] x 5 → [SELECT] to fine tune the parameter of Shift X.</li> </ul>
<p><b>Missing printing on the left or right side of label.</b></p>	<ul style="list-style-type: none"> <li>* Wrong label size setup.</li> </ul>	<ul style="list-style-type: none"> <li>* Set the correct label size.</li> </ul>
<p><b>RTC time is incorrect when reboot the printer.</b></p>	<ul style="list-style-type: none"> <li>* The battery has run down.</li> </ul>	<ul style="list-style-type: none"> <li>* Check if there is a battery on the main board.</li> </ul>
<p><b>Multi interface board doesn't work.</b></p>	<ul style="list-style-type: none"> <li>* The installation is incorrect.</li> </ul>	<ul style="list-style-type: none"> <li>* Check if the board is plugged in the right connector.</li> </ul>
<p><b>Power and Error LEDs are blinking fast.</b></p>	<ul style="list-style-type: none"> <li>* Power switch OFF and ON too fast.</li> </ul>	<ul style="list-style-type: none"> <li>* Turn off the printer and wait all LEDs are dark, and turn on the printer again.</li> </ul>
<p><b>Wrinkle Problem</b></p>	<ul style="list-style-type: none"> <li>* Printhead pressure is incorrect.</li> <li>* Ribbon installation is incorrect.</li> <li>* Media installation is incorrect.</li> <li>* Print density is incorrect.</li> <li>* Media feeding is incorrect.</li> </ul>	<ul style="list-style-type: none"> <li>* Please refer to the 4.2 chapter.</li> <li>* Please set the suitable density to have good print quality.</li> <li>* Make sure the label guide touch the edge of the media guide.</li> </ul>
<p><b>Gray line on the blank label</b></p>	<ul style="list-style-type: none"> <li>* The printhead is dirty.</li> <li>* The platen roller is dirty.</li> </ul>	<ul style="list-style-type: none"> <li>* Clean the printhead.</li> <li>* Clean the platen roller.</li> </ul>
<p><b>Irregular printing</b></p>	<ul style="list-style-type: none"> <li>* The printer is in Hex Dump mode.</li> <li>* The RS-232 setting is incorrect.</li> </ul>	<ul style="list-style-type: none"> <li>* Turn off and on the printer to skip the dump mode.</li> <li>* Re-set the Rs-232 setting.</li> </ul>

## 4.2 Mechanism Fine Adjustment to Avoid Ribbon Wrinkles


This printer has been fully tested before delivery. There should be no ribbon wrinkle presented on the media for general-purpose printing application. Ribbon wrinkle is related to the media thickness, print head pressure balance, ribbon film characteristics, print darkness setting...etc. In case the ribbon wrinkle happens, please follow the instructions below to adjust the printer parts.

	<p>The ribbon tension adjustment knob has 0 ~ 5 positions for adjustment.</p> 	
<p><b>Adjustable Printer Parts</b></p>	<p>The print head pressure adjustment knob has 5 levels of settings. Clockwise direction adjustment is to increase the print head pressure. Counter Clockwise adjustment can decrease the print head pressure.</p> 	
<p><b>Symptom</b></p>	<p>1. Wrinkle happens from label lower left to upper right direction ( “ / ” )</p>	<p>2. Wrinkle happens from label lower right to upper left direction ( “ \ ” )</p>
<p><b>Wrinkle Example</b></p>		

<p>If the wrinkle on the label starts from the lower left side to upper right side, please do following adjustment.</p> <ol style="list-style-type: none"> <li>1. Clockwise direction adjust the ribbon tension adjustment knob to “2” or “1” position. Then check if wrinkle is gone.</li> <li>2. Decrease the right side print head pressure adjustment knob setting 1 level per each adjustment then print the label again to check if wrinkle is gone.</li> <li>3. If the right side print head adjustment knob setting has been set to index 1 (the lowest pressure index), please increase the left side print head pressure.</li> <li>4. If the left side print head adjustment knob setting has been set to 5 (the highest pressure index) the wrinkle can't be avoid, please rotate the both knobs back to setting 1 then rotate the Z-axis mechanism adjustment knob clockwise for a few degrees and print again for fine tune the print head pressure distribution.</li> </ol> <p><b>Note for step 4:</b></p> <ul style="list-style-type: none"> <li>*Factory default setting, the Z-axis knob is rotated counter clockwise to the end of thread.</li> <li>*Turn the Z-axis mechanism adjustment knob clockwise until you feel the knob touch the mechanism for the first adjustment.</li> <li>* If the wrinkle is still there, please turn the Z-axis mechanism adjustment knob clockwise about 1/4 circle each time for adjustment</li> <li>* If the winkled direction is change from “/” to “\” by adjusting the Z-axis mechanism adjustment knob, please turn the Z axis mechanism adjustment knob counter clockwise to avoid the wrinkle.</li> </ul>	<p>If the wrinkle on the label starts from the lower right side to upper left side, please do following adjustment.</p> <ol style="list-style-type: none"> <li>1. Counter clockwise adjust the ribbon tension adjustment knob to “4” or “5” position. Then check if wrinkle is gone.</li> <li>2. Decrease the left side print head pressure adjustment knob setting 1 level per each adjustment then print the label again to check if wrinkle is gone.</li> <li>3. If the left side print head adjustment knob level has been set to index 1 (the lowest index), please increase the right side print head pressure.</li> </ol>
--	--

## 4.3 Adjustment Knob


### 4.3.1 Print head Pressure Adjustment Knob



Print head pressure adjustment knobs

The print head pressure adjustment knob has 5 levels of adjustment. Because the printer's paper alignment is to the left side of mechanism, different media widths require different pressure to print correctly. Therefore it may require to adjust the pressure knob to get your best print quality. For example, if the label width is 4", adjust both print head pressure adjustment knobs to the same level. If the label is less than 2" wide, increase the left side print head pressure by rotating the adjustment knob clockwise and decrease the right side pressure by rotating the adjustment knob counter-clockwise to level 1.

### 4.3.2 Ribbon Tension Adjustment Knob



The ribbon tension adjustment knob has 0 ~ 5 positions for adjustment. Because the printer's ribbon alignment is to the left side of mechanism, different ribbon or media widths require different tension to print correctly. Therefore it may require to adjust the ribbon tension knob to get your best print quality. Please refer to section 4.4 for more information.

### 4.3.3 Print Head Burn Line Adjustment Knob



The print head burn line adjustment knobs are used to fine tune the print quality for different thickness of media. Turning the knobs adjusts the print head's burn line forward or backward as it relates to the platen roller.

***Caution: Incorrectly adjusting these knobs can lead to poor print quality and may cause damage to the printer. Proceed with caution.***

The print head burn line default is set for general purpose printing media (plain paper and paper thickness less than 0.20mm).

Poor print quality when using paper thicker than 0.20mm may be due to the print head burn line not being at the optimized position. To improve the print quality, increase the head pressure or adjust the knobs counter-clockwise to move print head burn line toward the paper out direction then print again. Continue to adjust the burn line position and test print as necessary until the printout image is clear.


## 5. MAINTENANCE

This session presents the clean tools and methods to maintain your printer.

Please use one of following material to clean the printer.

- Cotton swab (Head cleaner pen)
- Lint-free cloth
- Vacuum / Blower brush
- 100% ethanol

2. The cleaning process is described as following

Printer Part	Method	Interval
<p><b>Print Head</b></p>	<ol style="list-style-type: none"> <li>1. Always turn off the printer before cleaning the print head.</li> <li>2. Allow the print head to cool for a minimum of one minute.</li> <li>3. Use a cotton swab (Head cleaner pen) and 100% ethanol to clean the print head surface.</li> </ol>	<p>Clean the print head when changing a new label roll</p>
		
<p><b>Platen Roller</b></p>	<ol style="list-style-type: none"> <li>1. Turn the power off.</li> <li>2. Rotate the platen roller and wipe it thoroughly with 100% ethanol and a cotton swab, or lint-free cloth.</li> </ol>	<p>Clean the platen roller when changing a new label roll</p>
<p><b>Tear Bar/Peel Bar</b></p>	<p>Use the lint-free cloth with 100% ethanol to wipe it.</p>	<p>As needed</p>
<p><b>Sensor</b></p>	<p>Compressed air or vacuum</p>	<p>Monthly</p>

<b>Exterior</b>	Wipe it with water-dampened cloth	As needed
<b>Interior</b>	Brush or vacuum	As needed

**Note:**

- Do not touch printer head by hand. If you touch it careless, please use ethanol to clean it.
- Please use 100% Ethenol. DO NOT use medical alcohol, which may damage the printer head.
- Regularly clean the print head and supply sensors once change a new ribbon to keep printer performance and extend printer life.

## UPDATE HISTORY

<b>Date</b>	<b>Content</b>	<b>Editor</b>
<b>2015/7/31</b>	Update section 3.12 (Peel-off kit installation)	Camille
<b>2015/8/12</b>	Modify section 2.1	Camille
<b>2015/10/2</b>	Add section 3.14 (Replacing cutter driver IC board)	Camille
<b>2015/10/21</b>	Modify section 1.1 (Recommended SD card specification)	Camille
<b>2015/11/9</b>	Modify section 4.2 Add chapter 4.3.2	Camille
<b>2015/12/17</b>	Add section 3.15 (Slot-in Wireless housing installation)	Camille



TSC Auto ID Technology Co., Ltd.

Corporate Headquarters

9F., No.95, Minquan Rd., Xindian Dist.,  
New Taipei City 23141, Taiwan (R.O.C.)

TEL: +886-2-2218-6789

FAX: +886-2-2218-5678

Web site: [www.tscprinters.com](http://www.tscprinters.com)

E-mail: [printer\\_sales@tscprinters.com](mailto:printer_sales@tscprinters.com)

[tech\\_support@tscprinters.com](mailto:tech_support@tscprinters.com)

Li Ze Plant

No.35, Sec. 2, Ligong 1st Rd., Wujie Township,  
Yilan County 26841, Taiwan (R.O.C.)

TEL: +886-3-990-6677

FAX: +886-3-990-5577